

## **INSTALLATION INSTRUCTIONS:**

NOTE: SLOW SPEED TRACK COMES ASSEMBLED WITH ALL BRACKETS.

- 1. MOUNT SLOW SPEED TRACK TO HEADER AND SET ECCENTRIC CAM SO THAT THE TRACK IS IN THE LOWEST POSITION. HAND TIGHTEN ALL SCREWS.
- HANG SLOW SPEED DOOR AND ROTATE ECCENTRIC CAM TO RAISE DOOR TO REQUIRED SILL CLEARANCE. ADJUST UPTHRUST ROLLERS TO CLEAR TRACK BY APPROXIMATELY  $\frac{1}{64}$  INCH. CHECK DOOR ALIGNMENT IN OPENED AND CLOSED POSITION AND CORRECT PER FIGURE 2. IF REQUIRED,

READJUST SLOW SPEED TRACK. TIGHTEN ALL SCREWS.

MOUNT FAST SPEED DOOR TRACK.

- WARNING -G.A.L. PROPRIETARY INFORMATION

REPRODUCTION AND/OR USE OF ALL OR ANY PART OF THIS (THESE) PAGE(S) OR DRAWING(S)

OR THE INFORMATION HEREIN, WITHOUT THE

- VIOLATORS WILL BE PROSECUTED -

MOUNT FAST SPEED DOOR. CHECK DOOR ALIGNMENT AND CORRECT PER FIGURE 2. 6.

EXPRESS PERMISSION OF G.A.L. MANUFACTURING CORPORATION IS STRICTLY PROHIBITED BY LAW. В SPRING CLOSER BASE & DRAWING UPDATE 12-18-13 TEMPLATE & HANGER UPDATED
DESCRIPTION 07-11-13

## TWO SPEED HATCH DOOR ASSEMBLY

G.A.L. MANUFACTURING CORP. 50 E. 153rd STREET, BRONX, N.Y. 10451 PHONE: (718) 292-9000, FAX: (718) 292-2034 www.GAL.com, info@GAL.com

DATE 11-03-1994 REV DOCUMENT No. В 8252

NOTE: 36x84 DOOR OPENING SHOWN

RIGHT HAND SHOWN

LEFT HAND OPPOSITE

TYPE "A" HANGER WITH SPRING DOOR CLOSER 24-72 DOOR OPENING